

# RemoteLinc<sup>™</sup> 2

INSTEON<sup>®</sup> Remote Control Switch (#2444A3)  
Owners Manual




INSTEON

<b>RemoteLinc 2</b> .....	<b>3</b>
<b>Features &amp; Benefits</b> .....	<b>4</b>
What's in the Box?.....	4
Required Accessories.....	4
Optional Accessories.....	5
<b>Getting Started</b> .....	<b>6</b>
<b>Setting up INSTEON Scenes</b> .....	<b>6</b>
Add RemoteLinc 2 Button to a Scene as a Controller.....	6
Remove RemoteLinc 2 Button from a Scene as a Controller .....	6
<b>Using RemoteLinc 2</b> .....	<b>7</b>
LED Behavior .....	8
Turn Unit On/Off (Pocket Mode).....	8
Stuck button.....	8
<b>Advanced Features</b> .....	<b>8</b>
Add Multiple Responders to a Scene (Multi-Link).....	8
Remove Multiple Responders from a Scene (Multi-Unlink) .....	9
Change Paddle / Scene Configuration (e.g. Change to 2 Scene Mode) .....	9
Turn LED Off (or Back On).....	10
Turn Beeper On During Usage (or Back Off) .....	10
Beeper Behavior.....	11
LED Behavior during Setup.....	11
Factory Reset .....	11
<b>Specifications</b> .....	<b>12</b>
<b>Troubleshooting</b> .....	<b>13</b>
<b>Certification and Warranty</b> .....	<b>15</b>
FCC & Industry Canada Compliance Statement.....	15
Limited Warranty .....	15
Limitations .....	15

## RemoteLinc 2

RemoteLinc 2 is the smallest and most versatile INSTEON Remote Control in the world. The 1 Scene Controller can easily be reconfigured to give you toggle control of up to 2 scenes and/or devices. RemoteLinc 2 can be:

- Handheld (wireless remote)
- Mounted on wall with no trim plate (wireless keypad)
- Mounted on wall in a single-gang Decorator trim plate (wireless keypad, built-in look)
- Mounted on wall in a multi-gang Decorator trim plate (add to the number of controllers in your room without hiring an electrician and/or tearing out drywall)
- Placed on a Tabletop Stand (sold separately)
- Clipped to your car's visor with Visor Clip (sold separately)



## Features & Benefits

Small, elegant design

Super-easy setup

Rechargeable battery included

Discreet On and Off buttons for 1 Scene

Can be reconfigured for 2 Scene triggers or 2 Scene On/Off toggle control

Can be installed into a single Decora opening (requires Wall-Mount Bracket)

Can be used as a table-top controller (requires Tabletop Stand)

Can be used as a visor-mounted remote control for lights, garage door opener etc. (requires Visor Clip)

LED blinks green when Turning a Scene On and red when turning a Scene Off

Slide switch for disabling buttons (“vacation” or “pocket” mode)

Stuck Button Mode – saves battery life by going to sleep if button stuck down

Beeper for setup ease

Recharges with standard USB charger with via Micro-USB Plug (5VDC)

Battery life exceeds 3 months

Battery charge LED indicator built-in

Low battery transmit warning (use with software to trigger email/text message)

All settings stored in stable memory which is maintained even without power

1 year warranty

## What's in the Box?

RemoteLinc 2

Rechargeable battery (pre-installed)

Quick-Start Guide


## Required Accessories

- A micro USB cable for connecting and recharging RemoteLinc 2 via USB port on a computer or USB power adapter.
- If the INSTEON device you intend to control does not receive RF signals (i.e., power line only), you will need at least one dual-band INSTEON device to convert the RF signals to power line signals.



Type A to Micro-B cable  
(2444B5)

## Optional Accessories



### Wall Mount Bracket (2444B4)

- Wall mount your RemoteLinc 2 anywhere
- Gang two or more together for more control
- Can be installed adjacent to existing wired-in switches
- RemoteLinc 2 can easily be removed for portability or recharging
- Use with any decorator wallplate
- 

Pair the Wall Mount Bracket with any decorator style wall plate (sold separately) for the perfect wireless wall switch solution.



### Tabletop Stand

(Available in the 2444Bxx kit)

- Perfect for a nightstand, kitchen counter or coffee table



### Visor Clip

(Available in the 2444Bxx kit)

- Control your home from your vehicle
- Turn lights on when you arrive and off as you leave



### USB Power Adapter (2444B6)

- For use with RemoteLinc 2 USB Charging Cable and any other device that charges via USB cable

## Getting Started

Fully charge your RemoteLinc 2 prior to programming or anytime the unit is not responding. RemoteLinc 2 charges via a USB cable (Type A to Micro-B, sold separately). The red charging LED will turn off once the battery has been fully charged (approximately 1 hour). To turn on RemoteLinc 2, simply slide the power switch to the on position.

Note: RemoteLinc 2 uses a subtle beeper sound to assist setup. It is recommended that you program the unit in a quiet area.

## Setting up INSTEON Scenes

Scene: One or more INSTEON devices which respond to an INSTEON controller. When the scene is activated (turned “on”), all devices return to the states they were at when the scene was programmed. INSTEON scenes let you activate dramatic lighting moods at the touch of a button. For example, you can set all the lights in a scene to dim to 50% or turn certain lights on while turning others off, all with the tap of a button on any INSTEON Controller. INSTEON scenes are easy to set up, just follow the directions below.

Maximum number of scenes in RemoteLinc 2 Switch: 2 (Default is 1)  
Scene Control Functions supported; On, Off, Press & hold Bright, Press & hold Dim, Double-tap Fast On and Double-tap Fast Off.

## Add RemoteLinc 2 Button to a Scene as a Controller

Follow the steps below to control a scene (one or more INSTEON devices).

- 1) Tap the RemoteLinc 2 switch (top or bottom paddle) – if in 2 scene mode, tap the top of the paddle for scene 1 or the bottom for scene 2
- 2) Adjust the scene responder to the “state” you want when the scene is activated from RemoteLinc 2 (e.g., 50%, 25% or even OFF)<sup>1</sup>
- 3) Press & hold RemoteLinc 2’s Set button until RemoteLinc 2 beeps  
*RemoteLinc 2’s LED will blink GREEN*
- 4) Press & hold the responder’s Set button until it beeps (or until its LED/load flashes)  
*RemoteLinc 2 will (Beep)-(Beep) and its LED will stop blinking*  
*Responder’s LED will stop blinking (it may also (Beep)-(Beep))*
- 5) Confirm that scene addition was successful by tapping on/off on your RemoteLinc 2  
*The Responder will toggle between the Scene on level and off*
- 6) If you wish to add more responders to RemoteLinc 2, repeat steps 1-5 for each additional scene responder (or see [Add Multiple Responders to a Scene](#))

<sup>1</sup> If the Responder is a multi-scene device such as a KeypadLinc, tap the Scene button you wish to control until its LED is in the desired state (on or off)

## Remove RemoteLinc 2 Button from a Scene as a Controller

If you are no longer going to use an INSTEON responder that is a scene responder of RemoteLinc 2, it is very important that you remove its scene membership. Otherwise, RemoteLinc 2 will retry every scene command repetitively, thus creating delays and shortening battery life.

- 1) Tap the RemoteLinc 2 switch (top or bottom paddle) - if in 2 scene mode, tap the top of the paddle for scene 1 or the bottom for scene 2

*The responder will respond*

- 2) Press & hold the RemoteLinc 2's Set button until it beeps

*RemoteLinc 2's LED will blink **GREEN***

- 3) Press & hold the RemoteLinc 2's Set button until it beeps again

*RemoteLinc 2's LED will blink **RED***

- 4) Press & hold the Responder's Set button until it double-beeps (or LED blinks)

*RemoteLinc 2 will **(Beep)-(Beep)** and its LED will stop blinking*

- 5) Confirm that Unlinking was successful by tapping on/off on your RemoteLinc 2

*The responder will not respond*

- 6) If you wish to remove multiple responders from RemoteLinc 2, repeat steps 1-5 for each additional responder (or see [Remove Multiple Responders from a Scene](#))

## Using RemoteLinc 2

### 1 Scene Mode (Default)

The switch controls scene members as follows:

Paddle	Tap	Press & hold	Double-tap
Top	Turn scene on	Brighten scene members until released	Turn scene members full-bright instantly
Bottom	Turn scene off	Dim scene members until released	Turn scene members off instantly

### 2 Scene Toggle Mode

The top and bottom paddle will control all its scene members as follows:

Last Command Sent	Tap	Press & hold	Double-tap
Off or Dim	Turn scene on	Brighten scene members until released	Turn scene members full-bright instantly
On or Bright	Turn scene off	Dim scene members until released	Turn scene members off instantly

### 2 Scene Non-Toggle Mode (Always On)

Each button will control all its scene members as follows:

Tap	Press & hold	Double-tap
Turn scene On	Brighten scene members until released	Turn scene members full-bright instantly

Note: Devices in scenes that respond to the scene trigger by turning off do not respond to scene dims and brights. Devices in Scenes that only support On/Off (such as switches and relays) do not respond to scene dims and brights.

## LED Behavior

RemoteLinc 2 has a two-color LED (Green & Red) which momentarily indicates whether an on or an off is being sent.

LED State	Meaning
Blink Green (Once)	On Sent
Blink Red (Once)	Off Sent
Blink Red (for a few seconds)	One or more scene members did not acknowledge (note: scene members may still have heard the scene command and adjusted their settings)

## Turn Unit On/Off (Pocket Mode)

The RemoteLinc 2 features a power switch located next to the Set button. If you plan on carrying the RemoteLinc 2 in your pocket it is recommended that you turn it off to prevent buttons from accidentally being pressed. This is also recommended if your RemoteLinc will not be in use for long periods of time.



## Stuck button

If a button on RemoteLinc 2 is held for more than 4 minutes, the RemoteLinc will automatically stop transmitting to preserve battery life. The RemoteLinc 2 will automatically turn back on when the button that was depressed is no longer being pressed.

## Advanced Features

### Add Multiple Responders to a Scene (Multi-Link)

- 1) Tap the RemoteLinc 2 paddle (top or bottom) – if in 2 scene mode, tap the top of the paddle for scene 1 or the bottom for scene 2
- 2) Press & Hold Set Button for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 3) Tap Set Button  
*RemoteLinc 2's LED will double-blink GREEN-GREEN*
- 4) Adjust Each Responder you wish to add to scene, then Press & Hold its Set Button until RemoteLinc 2 Double-Beeps  
*RemoteLinc 2's LED will continue to double-blink GREEN-GREEN*
- 5) When all your devices have been added, tap RemoteLinc 2's Set Button  
*RemoteLinc 2 will (Beep)-(Beep), its LED turns off & returns to Ready Mode*



## Remove Multiple Responders from a Scene (Multi-Unlink)

- 1) Tap the RemoteLinc 2 paddle (top or bottom) – if in 2 scene mode, tap the top of the paddle for scene 1 or the bottom for scene 2
- 2) Press & Hold Set Button for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 3) Press & Hold Set Button a 2<sup>nd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink RED*
- 4) Tap Set Button  
*RemoteLinc 2's LED will double-blink RED-RED*
- 5) For each Responder you wish to remove from scene, Press & Hold its Set Button until RemoteLinc 2 double-beeps  
*RemoteLinc 2's LED will continue to double-blink RED-RED*
- 6) When all your devices have been removed, tap RemoteLinc 2's Set Button  
*RemoteLinc 2 will (Beep)-(Beep), its LED will stop blinking & return to Ready Mode*

## Change Paddle / Scene Configuration (e.g. Change to 2 Scene Mode)

1. Press & Hold Set Button for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
2. Press & Hold Set Button a 2<sup>nd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink RED*
3. Press & Hold Set Button a 3<sup>rd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
4. Press & Hold Set Button a 4<sup>th</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink RED*
5. Tap Set Button  
*RemoteLinc 2's LED will blink RED-RED*
6. Press the appropriate paddle for the desired button/scene configuration

Desired Configuration	Paddle to Press
2 Scene Toggle	Bottom
2 Scene Non-Toggle (Always On)	Bottom twice
1 Scene (Default)	Top

*RemoteLinc 2 will (Beep)-(Beep), its LED turns off & returns to Ready Mode*

7. To confirm the configuration, tap the bottom of the paddle several times  
*RemoteLinc 2's LED will flash as follows*

Flash Pattern	Configuration
<b>RED</b> every tap	1 Scene
<b>GREEN</b> every tap	2 Scene Non-Toggle (Always On)
<b>GREEN / RED</b> alternating	2 Scene Toggle

### Turn LED Off (or Back On)

- 1) Press & Hold Set Button for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 2) Press & Hold Set Button a 2<sup>nd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink RED*
- 3) Press & Hold Set Button a 3<sup>rd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 4) Press the appropriate area of the paddle for the desired button/scene configuration

Desired LED Mode	Button to Press
LED Off	Bottom
LED On (default)	Top

*RemoteLinc 2 will (Beep)-(Beep), its LED turns off & returns to Ready Mode*

### Turn Beeper On During Usage (or Back Off)

- 1) Press & Hold Set Button for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 2) Press & Hold Set Button a 2<sup>nd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink RED*
- 3) Press & Hold Set Button a 3<sup>rd</sup> time for 3 seconds - until you hear a beep  
*RemoteLinc 2's LED will blink GREEN*
- 4) Tap Set Button  
*RemoteLinc 2's LED will blink GREEN-GREEN*
- 5) Press the appropriate area of the paddle for the desired button/scene configuration

Desired Beeper Mode	Area to Press
Off (Default)	Bottom
On	Top

*RemoteLinc 2 will (Beep)-(Beep), its LED turns off & returns to Ready Mode*

## Beeper Behavior

Command	Method	Beeper Disabled (Default)	Beeper Enabled
On	Tap	-	Beep
Off	Tap	-	Beep
Fast-On	Double-Tap	-	Beep
Fast-Off	Double-Tap	-	Beep
Begin Bright	Press & hold	-	Beep
Begin Dim	Press & hold	-	Beep
Setup Action			Beeper
Enter Setup Mode, Transition to next setup mode or Exit Setup Mode			Beep
Setup successful, return to Ready Mode			Beep-Beep
Return to Ready Mode after a longer than 3 minute time-out			3 Second (((((((Beep))))))))
Failure to add a scene responder			3 Second (((((((Beep))))))))
Exiting Stuck Button			3 Second (((((((Beep))))))))

## LED Behavior during Setup

RemoteLinc 2 has a two-color LED (Green & Red) which displays helpful information.

LED State	Meaning
Blinking Green slowly	Add Responder Setup Mode, or
	LED on/off Setup Mode
Blinking Red slowly	Remove Responder Setup Mode
Double-Blinking Green slowly	Multi-Add Responder Setup Mode, or
	Beeper on/off Setup Mode
Double-Blinking Red slowly	Multi-Remove Responder Setup Mode, or
	Keypad Configuration Setup Mode

## Factory Reset

The factory reset procedure clears all settings from RemoteLinc 2 including INSTEON scenes.

- 1) If possible, unlink (remove) all scene responders prior to performing factory reset
- 2) Turn RemoteLinc 2 off (slide power switch to left)
- 3) Press & Hold Set Button
- 4) While continuing to hold the Set Button, turn RemoteLinc 2 back on (slide power switch to the right)

*RemoteLinc 2 will (Beep) & LED stays solid GREEN*

*RemoteLinc 2 will long (Beep)*

5) Continue to Hold Set Button until the long beep stops

*LED turns solid RED*

6) Release Set Button

*RemoteLinc 2 will (Beep)-(Beep), its LED turns off & returns to Ready Mode*

## Specifications

General		
Product Name	RemoteLinc 2 – INSTEON Wireless Switch	
Brand	Smarthome	
Manufacturer Product Number	2444A3	
UPC	813922011616	
FCC ID	SBP2444A	
Patent Number	7,345,998 US, International Patents Pending	
Warranty	1 Year, Limited	
INSTEON		
Scenes	1 (default), configurable to 2	
Scene Configurations	1 On/Off (default), 2 Toggle or 2 Always On	
Maximum Scene Links	400	
Scene Commands Supported	On	Off
	Begin Brightening	Begin Dimming
	End Brightening	End Dimming
	Fast On	Fast Off
Software Configurable	Yes	
X10 Support	None	
Operation		
LED Type	Two-color: Green and Red	
LED during Use	Green Flash Once	On (sent)
		Bright
		Fast-On
	Red Flash Once	Off
		Dim
		Fast-Off
	Red Blink for ~3 Seconds	Scene Acknowledge Missing
LED	Always used for setup, default On during use	
Setup Button	Yes	
On/Off Switch	Yes	

Beeper	Yes, configurable
Battery Charging LED	Yes, Embedded (shines red through case during charge)
RF Range	50' Line-of-Sight
Retains all settings without power	Yes, all saved in Non-volatile EEPROM
<b>Mechanical</b>	
Color	White
Plastic	UV Stabilized ABS
Button Configurations	1 Scene (standard), 2 Scene (optional button kit)
Dimensions	2.6" H x 1.3" W x 0.39" D
Weight (w/battery)	1 Oz.
Button Style	Plastic Paddles over Contact Switches
Optional Hardware	Wall Mount
	Tabletop Stand
	Visor Clip
Operating Environment	Indoors, 32°F to 104°F, up to 85% relative humidity
<b>Electrical</b>	
Battery type	3.7 VDC Lithium Polymer, Rechargeable, non-replaceable
Battery life (between charges)	> 3 months under standard usage
Battery Re-charging cycles	> 500 recharging cycles
Recharging jack	Standard, Micro-USB, 5VDC
Recharging time	~1 hour
Sends Low Battery Warning	Yes

## Troubleshooting

Problem	Possible Cause	Solution
RemoteLinc 2 won't add a scene responder	RemoteLinc 2 may be out of range of nearest dual-band INSTEON device (hopper)	Try moving an access point or other dual-band plug-in module closer to RemoteLinc 2
	The INSTEON signal may not be getting to the "vicinity" of responder	Make sure phases are bridged, add additional INSTEON devices and/or move around existing INSTEON devices
	Large appliances, such as refrigerators or air conditioners, may be producing electrical noise on the power line	Install a power line noise filter (e.g. #1626-10) to filter electrical noise and minimize signal attenuation
	Other electrical devices, such as computers, televisions, or power strips, may be absorbing the INSTEON signal	
RemoteLinc 2 will not turn a Responder On (it may turn it off)	Ramp Rate may be Extremely Slow Or Responder may be Linked at OFF	Re-link to responder with fast Ramp Rate

Problem	Possible Cause	Solution
Responder's Load doesn't appear to turn on right away	The Ramp Rate may be set too slow.	Re-link to responder with fast Ramp Rate
Responder(s) is taking a long time to respond to a RemoteLinc 2	RemoteLinc 2 may be sending commands to a responder(s) that is no longer in use	Remove all unused Responders from the RemoteLinc 2. HINT: If you are using home automation software, you can easily check scene membership and eliminate unnecessary Links
		If the above doesn't work, try the solutions for "RemoteLinc 2 will not turn a Responder On"
RemoteLinc 2 blinks red after I turn a scene On or Off	One or more scene members not responding Or One or more scene members not responding AND HouseLinc (or other software) is attempting to communicate to RemoteLinc 2	Monitor for recurrence and if recurs: a) Remove all scene responders that are no longer in use, or b) Add INSTEON devices for better signaling
RemoteLinc 2 is locked up	Glitch	Power cycle: Turn unit Off (slide switch to left), wait 10 seconds and turn back on
		Perform a factory reset on RemoteLinc 2

If you have tried these solutions, reviewed this Owner's Manual, and still cannot resolve an issue you are having, please call: 800-762-7845

# Certification and Warranty

## **FCC & Industry Canada Compliance Statement**

This device complies with FCC Rules Part 15 and Industry Canada RSS-210 (Rev. 7). Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The digital circuitry of this device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna of the device experiencing the interference
- Increase the distance between this device and the receiver
- Connect the device to an AC outlet on a circuit different from the one that supplies power to the receiver
- Consult the dealer or an experienced radio/TV technician

**WARNING:** Changes or modifications to this device not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Limited Warranty**

Seller warrants to the original consumer purchaser of this product that, for a period of one year from the date of purchase, this product will be free from defects in material and workmanship and will perform in substantial conformity to the description of the product in this Owner's Manual. This warranty shall not apply to defects or errors caused by misuse or neglect. If the product is found to be defective in material or workmanship, or if the product does not perform as warranted above during the warranty period, Seller will either repair it, replace it, or refund the purchase price, at its option, upon receipt of the product at the address below, postage prepaid, with proof of the date of purchase and an explanation of the defect or error. The repair, replacement, or refund that is provided for above shall be the full extent of Seller's liability with respect to this product. For repair or replacement during the warranty period, call the INSTEON Gold Support Line at 800-762-7845 with the Model # and Revision # of the device to receive an RMA# and send the product, along with all other required materials to:

**Smarthome**  
**ATTN: Receiving**  
**16542 Millikan Ave.**  
**Irvine, CA 92606-5027**

## **Limitations**

The above warranty is in lieu of and Seller disclaims all other warranties, whether oral or written, express or implied, including any warranty or merchantability or fitness for a particular purpose. Any implied warranty, including any warranty of merchantability or fitness for a particular purpose, which may not be disclaimed or supplanted as provided above shall be limited to the one-year of the express warranty above. No other representation or claim of any nature by any person shall be binding upon Seller or modify the terms of the above warranty and disclaimer.

Home automation devices have the risk of failure to operate, incorrect operation, or electrical or mechanical tampering. For optimal use, manually verify the device state. Any home automation device should be viewed as a convenience, but not as a sole method for controlling your home.

In no event shall Seller be liable for special, incidental, consequential, or other damages resulting from possession or use of this device, including without limitation damage to property and, to the extent permitted by law, personal injury, even if Seller knew or should have known of the possibility of such damages. Some states do not allow limitations on how long an implied warranty lasts and/or the exclusion or limitation of damages, in which case the above limitations and/or exclusions may not apply to you. You may also have other legal rights that may vary from state to state.

U.S Patent No. 7,345,998, International patents pending  
© Copyright 2011 Smarthome, 16542 Millikan Ave., Irvine, CA 92606, 800-762-7845, [www.smarthome.com](http://www.smarthome.com)