

Quick Start Guide

INSTEON® Hub

Model: 2242-222, 2242-422, 2242-442, 2242-522



Good Choice 😊


The Hub enables you to setup, control and manage your INSTEON devices from either your smartphone/tablet or PC.

Getting Started

Connect Hub to router using *only* the included Ethernet cable. Then connect Hub to wall outlet (not a power strip).

What you'll need

- Available port on your router
- Available wall outlet



Option 1: Use Hub with Smartphone/Tablet

- 1) Connect your smartphone/tablet to your router via WiFi
- 2) Download the INSTEON for Hub app
- 3) Launch and follow the onscreen instructions

What you'll need

- Smartphone or tablet running iOS or Android

Option 2: Use Hub with INSTEON Compatible Software

Do not use this option if you are using or plan to use the Hub with the INSTEON for Hub app.


- 1) Install software
- 2) Follow software instructions for adding Hub as a computer interface

What you'll need

- INSTEON compatible software that supports the Hub as a computer interface
- Computer connected to the router (WiFi or Ethernet)

Mount Hub on Wall

Simply screw two screws (we recommend using #6 drywall screws) through the marks in the drawing below (leaving head of screw about 1/4" from the wall) and hang Hub on the screws (you can then tear this sheet off).



Support

Visit: <http://www.insteon.com/support> for complete manual, online tech support and latest product documents.
Call: INSTEON Support Line at 866-243-8022

Certifications

Certification

This product has been thoroughly tested by Intertek ETL, a nationally recognized independent third-party testing laboratory. The North American ETL Listed mark signifies that the device has been tested to and has met the requirements of a widely recognized consensus of U.S. and Canadian device safety standards, that the manufacturing site has been audited, and that the manufacturer has agreed to a program of quarterly factory follow-up inspections to verify continued conformance.

FCC and Industry Canada Compliance Statement

This device complies with FCC Rules Part 15 and Industry Canada RSS-210 Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The digital circuitry of this device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna of the device experiencing the interference
- Increase the distance between this device and the receiver
- Connect the device to an AC outlet on a circuit different from the one that supplies power to the receiver
- Consult the dealer or an experienced radio/TV technician

WARNING: Changes or modifications to this device not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ETL/UL Warning (Safety Warning)

CAUTION: To reduce the risk of overheating and possible damage to other equipment, do not install this device to control a receptacle, a motor-operated appliance, a fluorescent lighting fixture, or a transformer-supplied appliance.

Gradateurs commandant une lampe à filament de tungstène – afin de réduire le risque de surchauffe et la possibilité d'endommagement d'autres matériels, ne pas installer pour commander une prise, un appareil à moteur, une lampe fluorescente ou un appareil alimenté par un transformateur.